

Cherry - Almond Muffins

1 packet **Cherry Almond Dip Mix**

1 egg

1 cup buttermilk

1/4 cup vegetable oil

1-1/4 cup flour

2/3 cup sugar

1-1/4 tsp. baking soda

1/4 tsp. salt



Preheat oven to 450°.

Grease muffin pan. Beat egg in a 2-1/2 qt. bowl. Stir in buttermilk, oil and **Cherry Almond Dip Mix**. Mix well. Stir in remaining ingredients all at once until flour is moist. (Batter may still be lumpy.) Fill each cup 2/3 full of mixture. Bake for 20 minutes or until toothpick comes out clean. Enjoy!



© Country Home Creations

1-800-457-3477

www.countryhomecreations.com